

## Course Outline

### L1-L5 Specifications, models and loop-shaping by hand

1. Introduction and system representations
2. Stability and robustness
3. Specifications and disturbance models
4. Control synthesis in frequency domain
5. Case study


### L6-L8 Limitations on achievable performance

### L9-L11 Controller optimization: Analytic approach

### L12-L14 Controller optimization: Numerical approach

## Yesterdays lecture

- Introduction/examples
- Overview of course
- Review linear systems
  - Time-domain models
  - Frequency-domain models



## Lecture 2: Stability and Robustness

- Stability
- Robustness and sensitivity
- Small gain theorem

Demo: "Inverted pendulum"

## Stability is crucial

- bicycle
- JAS 39 Gripen
- Mercedes A-class
- ABS brakes

## Stability of autonomous systems

The autonomous system

$$\frac{dx}{dt} = Ax(t)$$

is called exponentially stable if the following equivalent conditions hold

1. There exist constants  $\alpha, \beta > 0$  such that

$$|x(t)| \leq \alpha e^{-\beta t} |x(0)| \quad \text{for } t \geq 0$$

2. All eigenvalues of  $A$  are in the left half plane (LHP), that is all eigenvalues have negative real part.
3. All roots of the polynomial  $\det(sI - A)$  are in the LHP.

## Eigenvalues determine stability

The matrix  $A$  can always be written on the form

$$A = U \begin{bmatrix} \lambda_1 & & * \\ & \ddots & \\ 0 & & \lambda_n \end{bmatrix} U^{-1}. \quad \text{Hence } e^{At} = U \begin{bmatrix} e^{\lambda_1 t} & & * \\ & \ddots & \\ 0 & & e^{\lambda_n t} \end{bmatrix} U^{-1}.$$

The number  $\lambda_1, \dots, \lambda_n$  are the eigenvalues of  $A$ .

$e^{At}$  decays exponentially if and only if  $\text{Re}\{\lambda_k\} < 0$  for all  $k$ .

## Stability of input-output maps

The transfer function  $G(s)$  of a continuous time system, is said to be input-output stable (I/O-stable, or often just called "stable") if the following equivalent conditions hold:


- All poles of  $G$  have negative real part ( $G$  is Hurwitz stable)
- The impulse response of  $G$  decays exponentially.

**Warning:** There may be unstable pole-zero cancellations (which also render the system either uncontrollable and/or unobservable) and these may not be seen in the transfer function!!

For discrete time systems the corresponding conditions are : a pulse transfer function  $G(z)$  of a discrete time system

- All poles of  $G$  are inside the unit circle ( $G$  is Schur stable).
- The pulse response of  $G$  decays exponentially.

## Stability of feedback loops



The closed loop system is input-output stable if and only if all solutions to the equation


$$1 + G_0(s) = 0$$

are in the left half plane (i.e. has negative real part).

## The Nyquist criterion

If  $G_0(s)$  is stable, then the closed loop system  $[1 + G_0(s)]^{-1}$  is stable if and only if the Nyquist curve does not encircle  $-1$

The difference between the number of unstable poles in  $[1 + G_0(s)]^{-1}$  and the number of unstable poles in  $G_0(s)$  is equal to the number of times the point  $-1$  is encircled by the Nyquist plot in the clockwise direction.



NOTE: Matlab gives Nyquist plot for both positive and negative frequencies!

## Sensitivity and Robustness

- How sensitive is the closed loop system to model errors?
- How do we measure the “distance to instability”?
- Is it possible to guarantee stability for all systems within some distance from the ideal model?


## Amplitude and phase margin

Amplitude margin  $A_m$


$$\arg G(i\omega_0) = -180^\circ, \quad |G(i\omega_0)| = \frac{1}{A_m}$$

Phase margin  $\phi_m$


$$|G(i\omega_c)| = 1, \quad \arg G(i\omega_c) = \phi_m - 180^\circ$$



## Mini-problem



Nominally  $k = 1$ ,  $c = 1$  and  $T = 0$ . How much margin is there in each of the parameters before the system becomes unstable?



## Mini-problem — Stability margins




Figure : Nyquist/Bode plots for the nominal transfer function  $\frac{(s+1)}{(s^2+s+1)}$

For  $k = c = 1$  the open loop transfer function is

$$\frac{s+1}{s^2+s+1} e^{-sT}$$

The phase margin is  $109 \cdot \frac{\pi}{180}$  rad at  $\omega = 1.4$  rad/s.

A time-delay  $T$  corresponds to a phase-delay  $\arg\{e^{-i\omega T}\} = -\omega T$


Thus the time-delay margin is  $109 \cdot \frac{\pi}{180} / 1.4 \approx 1.35$  sec.

## Mini-problem — Stability margins

Closed loop without delay ( $T = 0$ ):

$$\begin{aligned} G_{cl}(s) &= \frac{P(s)C(s)}{1 + P(s)C(s)} \\ &= \frac{\frac{k(s+1)}{s^2+cs+1}}{\left(1 + \frac{k(s+1)}{s^2+cs+1}\right)} \\ &= \frac{k(s+1)}{s^2+cs+1+ks+k} = \frac{k(s+1)}{s^2+s(k+c)+(1+k)} \end{aligned}$$

## How sensitive is $T$ to changes in $P$ ?



$$Y(s) = \underbrace{\frac{P(s)C(s)}{1 + P(s)C(s)}}_{T(s)} R(s)$$


$$\frac{dT}{dP} = \frac{d}{dP} \left(1 - \frac{1}{1+PC}\right) = \frac{C}{(1+PC)^2} = \frac{T}{P(1+PC)}$$

Define the sensitivity function,  $S$ :

$$S := \frac{d(\log T)}{d(\log P)} = \frac{dT/T}{dP/P} = \frac{1}{1+PC}$$

and the complementary sensitivity function  $T$ :

$$T := 1 - S = \frac{PC}{1+PC}$$



Note that the

- ▶ complementary sensitivity function  $T$  is the transfer function  $G_{r \rightarrow y}$
- ▶ sensitivity function  $S$  is the transfer function  $G_{m \rightarrow y}$

$$S + T = 1$$


Note: there are **four different transfer functions** for this closed-loop system and all have to be stable for the system to be stable!

It may be OK to use an unstable controller  $C$

## Nyquist plot illustration

The sensitivity function measures the distance from the Nyquist plot to  $-1$ .

$$R^{-1} = \sup_{\omega} \left| \frac{1}{1 + P(i\omega)C(i\omega)} \right|$$




## Lecture 2

- ▶ Stability
- ▶ Robustness and sensitivity
- ▶ **Small gain theorem**

## Robustness

How large perturbations  $\Delta(i\omega)$  can be tolerated without instability?



## Vector Norm and Matrix Norm

For  $x \in \mathbf{R}^n$ , we use the " $L_2$ -norm"


$$|x| = \sqrt{x^T x} = \sqrt{x_1^2 + \dots + x_n^2}$$

For  $M \in \mathbf{R}^{n \times n}$ , we use the " $L_2$ -induced norm"

$$\|M\| := \sup_x \frac{|Mx|}{|x|} = \sup_x \sqrt{\frac{x^T M^T M x}{x^T x}} = \sqrt{\bar{\lambda}(M^T M)}$$

Here  $\bar{\lambda}(M^T M)$  denotes the largest eigenvalue of  $M^T M$ . The fraction  $|Mx|/|x|$  is maximized when  $x$  is a corresponding eigenvector.

Different gains in different directions:  $\begin{bmatrix} y_1 \\ y_2 \end{bmatrix} = \begin{bmatrix} 2 & 4 \\ 0 & 3 \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix}$



Example: matlab-demo

### Example

Matlab-code for singular value decomposition of the matrix

$$A = \begin{bmatrix} 2 & 4 \\ 0 & 3 \end{bmatrix}$$

SVD:

$$A = U \cdot S \cdot V^*$$

where both the matrices  $U$  and  $V$  are unitary (i.e. have orthonormal columns s.t.  $V^* \cdot V = I$ ) and  $S$  is the diagonal matrix with (sorted decreasing) singular values  $\sigma_i$ .

Multiplying  $A$  with a input vector along the first column in  $V$  gives

$$A \cdot V_{(:,1)} = USV^* \cdot V_{(:,1)} = US \begin{bmatrix} 1 \\ 0 \end{bmatrix} = U_{(:,1)} \cdot \sigma_1$$

That is, we get maximal gain  $\sigma_1$  in the output direction  $U_{(:,1)}$  if we use an input in direction  $V_{(:,1)}$  (and minimal gain  $\sigma_n = \sigma_2$  if we use the last column  $V_{(:,n)} = V_{(:,2)}$ ).

```
>> A=[2 4 ; 0 3]
A =
     2     4
     0     3
>> [U,S,V]=svd(A)
U =
    0.8416   -0.5401
    0.5401    0.8416
S =
    5.2631         0
         0    1.1400
V =
    0.3198   -0.9475
    0.9475    0.3198
```

```
>> A*V(:,1)
ans =
    4.4296
    2.8424
```

```
>> U(:,1)*S(1,1)
ans =
    4.4296
    2.8424
```

## The $L_2$ -norm of a signal

For  $y(t) \in \mathbf{R}^n$  the " $L_2$ -norm"

$$\|y\|_2 := \sqrt{\int_0^\infty |y(t)|^2 dt} \quad \text{is equal to} \quad \sqrt{\frac{1}{2\pi} \int_{-\infty}^\infty |Ly(i\omega)|^2 d\omega}$$

The equality is known as Parseval's formula

**The  $L_2$ -gain of a system** For a system  $S$  with input  $u$  and output  $S(u)$ , the  $L_2$ -gain is defined as

$$\|S\| := \sup_u \frac{\|S(u)\|_2}{\|u\|_2}$$

## Miniproblem

What are the gains of the following systems?

1.  $y(t) = -u(t)$  (a sign shift)
2.  $y(t) = u(t - T)$  (a time delay)
3.  $y(t) = \int_0^t u(\tau) d\tau$  (an integrator)
4.  $y(t) = \int_0^t e^{-(t-\tau)} u(\tau) d\tau$  (a first order filter)

## The $L_2$ -gain from frequency data

Consider a stable system  $S$  with input  $u$  and output  $S(u)$  having the transfer function  $G(s)$ . Then, the system gain

$$\|S\| := \sup_u \frac{\|S(u)\|_2}{\|u\|_2} \text{ is equal to } \|G\|_\infty := \sup_\omega |G(i\omega)|$$

**Proof.** Let  $y = S(u)$ . Then

$$\|y\|^2 = \frac{1}{2\pi} \int_{-\infty}^{\infty} |Ly(i\omega)|^2 d\omega = \frac{1}{2\pi} \int_{-\infty}^{\infty} |G(i\omega)|^2 \cdot |Lu(i\omega)|^2 d\omega \leq \|G\|_\infty^2 \|u\|^2$$

The inequality is arbitrarily tight when  $u(t)$  is a sinusoid near the maximizing frequency.

Example: Consider the transfer function matrix  $G(i\omega)$

$$G(s) = \begin{bmatrix} \frac{2}{s+1} & \frac{4}{2s+1} \\ \frac{s}{s^2+0.1s+1} & \frac{3}{s+1} \end{bmatrix}$$

```
>> s=tf('s')
>> G=[ 2/(s+1) 4/(2*s+1); s/(s^2+0.1*s+1) 3/(s+1)];
>> sigma(G) % plot sigma values of G wrt fq
>> grid on
>> norm(G,inf) % infinity norm = system gain
ans =
    10.3577
```





Figure : The singular values of the transfer function matrix (prev slide). Note that  $G(0)=[2, 4; 0, 3]$  which corresponds to  $M$  in the SVD-example above.  $\|G\|_\infty = 10.3577$ .

## The Small Gain Theorem



Assume that  $S_1$  and  $S_2$  are input-output stable. If  $\|S_1\| \cdot \|S_2\| < 1$ , then the gain from  $(r_1, r_2)$  to  $(e_1, e_2)$  in the closed loop system is finite.

## Proof


Define  $\|y\|_T = \sqrt{\int_0^T |y(t)|^2 dt}$ . Then  $\|S(y)\|_T \leq \|S\| \cdot \|y\|_T$ .

$$\begin{aligned} e_1 &= r_1 + S_2(r_2 + S_1(e_1)) \\ \|e_1\|_T &\leq \|r_1\|_T + \|S_2\| (\|r_2\|_T + \|S_1\| \cdot \|e_1\|_T) \\ \|e_1\|_T &\leq \frac{\|r_1\|_T + \|S_2\| \cdot \|r_2\|_T}{1 - \|S_1\| \cdot \|S_2\|} \end{aligned}$$


This shows bounded gain from  $(r_1, r_2)$  to  $e_1$ .

The gain to  $e_2$  is bounded in the same way.


## Application to robustness analysis



The diagram can be redrawn as



## Application to robustness analysis



The small gain theorem guarantees stability if

$$\|\Delta\|_\infty \cdot \left\| \frac{GC}{1+GC} \right\|_\infty < 1$$